

M40XDWD

TO OPEN:

1. Set lock to the concealed password on back of package.
2. Slide lever to open.

TO SET YOUR OWN PASSWORD:

3. Locate 'reset' tool on back of package. Insert tool inside of lock.  
Lock must be open to reset.
4. Push tool in and turn 90°.
5. Set to desired password. Turn and remove tool.
6. Be sure to record your new password at [masterlockvault.com](http://masterlockvault.com).
7. Close lock and scramble dials to close.